

Assembly

Tools you'll need:

- (2) 1/2" Box wrenches or sockets
1. Lay the Chassis flat and unfold it with the "Top Side" label facing up.
 2. Locate the small box with the hardware.
 3. Using the 1/2" wrench, secure the 2 sides of the unfolded Chassis with the six, 5/16-18 x 0.75 bolts and nylon lock nuts in the 3 places shown.

